

LEYCO[®]-RM 25

ACTIVE ACIDIC CLEANER TO BREAKDOWN GREASE AND PROTEINS



- Quickly breakdown areas of protein and grease
- Automatically solves contamination
- Non flammable
- Free of organic solvents and chlorinated hydrocarbons
- Smell-neutral
- Economical
- Biodegradable
- UBA-Nr.: 0595 - 0072

LEYCO®-RM 25 is suitable for application in the foodstuffs sector, sanitary cleaning in agriculture.

LEYCO®-RM 25 removes fast and effectively areas of fat and protein from acid-insensitive surfaces.

It is advisable to test the suitability of this product on a small area before it is applied to the whole.

LEYCO®-RM 25 is not usable on acid-sensitive surfaces.



LEYCO®-RM 25

Product-No. 20.174

ACTIVE ACIDIC CLEANER TO BREAKDOWN GREASE AND PROTEINS

DESCRIPTION

LEYCO®-RM 25 is a high-activity basic cleaner based on inorganic substances and Tensides. It is free from organic solvents and contains no chlorinated hydrocarbons.

BENEFITS

- non flammable
- bio degradable
- economical
- automatically solves contamination
- smell-neutral

TECHNICAL DATA

Density:	1,1 g/cm ³
Appearance:	yellowish, clearly
Dilution:	HD devices: 1 - 5% (30°C) 0.3 - 2% (60°C)
Voransatz f. of HD devices:	1-25 %
Voransatz f. Vorsprühgeräte:	1 + 3 T. Wasser
pH value:	2

APPLICATION

Depending upon contamination LEYCO®-RM 25 can be applied by sprayer at a 25% solution, or applied by high pressure equipment at a ratio of 1-5 %.

After a short impact time rinse thoroughly with water. Do not allow LEYCO®-RM 25 to dry on the surface.

LEYCO®-RM 25 was developed for maintenance cleaning by means of high pressure equipment or spraying equipment. It is most economically used where a 25% dilution is used, allowed to react and the washed with plenty of water through a high pressure cleaner.

STORAGE

Protect against frost. Store in sealed container.
Minimum shelf-life 30 months.

PRECAUTION

Avoid Contact with eyes and skin. Immediately wash off any splashes from the skin with plenty of clean water. Use rubber gloves when used by hand. If splashed into eyes, immediately wash out with plenty of water and seek medical advise.

UBA-No.: 0595 - 0072

REMARK

Whilst information and/or specification contained herein is to the best of our knowledge true and accurate, and is based on many years experience, we cannot accept any liability either directly or indirectly arising from the use of our products, whether or not in accordance with any advice, specification or recommendation given by us, as we have no direct or continuous control over how or where our products are applied.

LEYDE-PRODUCTS are guaranteed against defective materials and manufacture and are sold subject to its standard terms and conditions of sale. 09.01.04

LEYCO CHEMISCHE LEYDE GmbH, Industriestr. 155, D - 50999 Cologne,

Tel.: +49 2236 - 9 66 00 0, Fax: +49 2236 - 9 66 00 11,

email: leycochem@leyde.com, internet: www.leyde.com