

LEYCO[®]-RM 31

HIGH-ACTIVITY ONE BASIC CLEANER CONCENTRATE



- Automatically strong dissolve contamination fast and arrearsless
- Suitably for all alkali-steady surfaces
- Freely of dangerous Vapors
- Not inflammable
- Smell-neutrally
- Biologically degradably
- Economically

The areas of application of LEYCO®-RM 31 are variously, e.g. foodstuffs sector, agriculture, industry, vehicle and tank cleaning.

LEYCO®-RM 31 removes fast and arrearsless heavy fat-, for oil-, soot and tar contamination from alkali-steady surfaces. If ambiguity exists over the alkali stability of the surface which can be cleaned, preliminary tests must be absolutely accomplished to the material stability.

The processing by means of HD devices takes place with 1-3%.



LEYCO®-RM 31

Product-No. 20.175

HIGH-ACTIVITY BASIC CLEANER CONCENTRATES

DESCRIPTION

LEYCO®-RM 31 is a high-activity basic cleaner on basis of inorganic substances and Tensiden. LEYCO®-RM 31 is free from organic solvents and contains no chlorinated hydrocarbons.

BENEFITS

- not inflammable
- no dangerous vapors
- biologically degradable
- economically
- solves contamination automatically
- smell-neutrally

TECHNICAL DATA

Density: 1.36 g/cm³
Appearance: yellowish, clearly
Dilution: HD devices: 1-3 %
Vorspruehen: 1-25 %
pH value: 14

APPLICATION

Depending upon contamination LEYCO®-RM 31 is laid on as Vorsprueh solution by means of Vorspruehgeraet (1 - 25 %) or by means of HD equipment (1 - 3%). Rinse after short impact time thoroughly with water. LEYCO®-RM 31 to dry up do not leave. LEYCO®-RM 31 was developed particularly for heavy contamination. For the maintenance cleaning by means of HD equipment or Vorsprueh equipment we recommend our product LEYCO®-RM 81. One obtains most economic success by means of Vorspruehen with diluted LEYCO®-RM 31 and a following cleaning by means of plentifully clear water with vapor or HD equipment.

STORAGE

Frost-protected in the carefully closed container store. Minimum shelf-life 30 months.

PRECAUTION

Contact with eyes and skin avoid. Splashes immediately with much clear water rinse off. Use rubber gloves by hand with use. Absolutely consider the danger references on the label. Rinse with eye contact thoroughly with much water and doctor consult.

REMARK

Whilst information and/or specification contained herein is to the best of our knowledge true and accurate, and is based on many years experience, we cannot accept any liability either directly or indirectly arising from the use of our products, whether or not in accordance with any advice, specification or recommendation given by us, as we have no direct or continuous control over how or where our products are applied.

LEYDE-PRODUCTS are guaranteed against defective materials and manufacture and are sold subject to its standard terms and conditions of sale.

09.01.04

LEYCO CHEMISCHE LEYDE GmbH, Industriestr. 155, D - 50999 Cologne,

Tel.: +49 2236 - 9 66 00 0, Fax: +49 2236 - 9 66 00 11,

email: leycochem@leyde.com, internet: www.leyde.com